

# **CASA ADHESIVE, INC.**

## **CASA 465 QUICK-HIDE**

### **Application Procedures**

- Ambient conditions should be 60 degrees F or above for coatings to perform per data sheet information.
- Materials to be bonded should be clean, dry and dust free. Any petroleum based products such as oil or grease can prevent suitable bonding.
- Quick-Hide can be brushed, rolled or sprayed. Different textures are accomplished using varying application techniques. When spraying, textured finishes are best achieved using a spatter gun. Spray guns should be adjusted to give a paint-like spray pattern. Hold the spray gun 8-12 inches from the surface with each pass to ensure uniform coverage.
- Allow this coating to thoroughly dry and harden. Under normal ambient room temperatures, this will take less than 1 hour. The coating will be dry to the touch in 30 minutes. Using a fan blowing over the coated surface may accelerate drying time.
- The final cure is achieved once the residual water has evaporated. Although water evaporation happens quickly, it is recommended users wait 24 hours before performing any final testing.
- New associates assigned to industrial coatings positions should be trained in all required procedures.
- Casa's water-based coatings must be used in conjunction with stainless steel or plastic parts where the coatings comes in contact with hose fittings, spray guns, diaphragm pumps or pressure pots.
- Casa's 465 water-based, non-toxic coatings eliminate associate health issues, flash fire issues and eliminate environmental VOC emissions.

**206 Nance Rd NE Calhoun GA 30701**  
**Phone: 888-685-0025 Fax: 888-781-5255**