

# **CASA ADHESIVE, INC.**

## **PT Canister Disposal Procedures**

### **Use Only For**

### **Casa Water-Based, “0” VOC Adhesives & Cleaners**

1. When a canister is empty of adhesive or cleaner, turn off the canister valve and pull the spray gun trigger to relieve the remaining pressure. Now detach the hose. You should immediately re-attach the hose to a new canister, or clean it with Casa PT Cleaner.
2. Now take the empty canister of Casa’s adhesive or cleaner, turn the empty canister upside down and point the valve into an empty pail or box and open the valve slowly to make sure no adhesive or cleaner is left inside.
3. Once you have verified the canister is empty of adhesive or cleaner, open the valve all the way to let the remaining non-flammable gas escape.
4. Once all the left over gas has escaped turn the canister back to its upright position and set it on the floor.
5. With a hammer and a flathead screwdriver, pop the round disk cover off the rupture disk located just under the valve near the top of the canister.
6. You now have an open container that can be disposed of as an open container, just like a pail; or can be recycled as scrap metal.

**206 Nance Rd NE Calhoun GA 30701  
Phone: 888-685-0025 Fax: 888-781-5255**